


## HCS-8522 Dual PC Server Hot Spare Software



Start to backup interface



Backing up interface

---

### Functions

Dual PC server hot-spare is a disaster protective structure. If the main operating computer breaks down during a conference, the backup computer immediately substitutes the main computer and continues conference management.

After connection to main operating computer, the backup console application first starts an automatic backup (incl. database and conference related information). If there is any change in the database, the backup console application will update backup automatically.

---

### Ordering Information

HCS-8522.....Dual PC Server Hot Spare Software